

## A. Transferring a New Rhythm from SD Card to Casio AT-3/5

### **1 st Step : Formatting the SD Card to digital keyboard**

1. Turn on the digital keyboard.
2. Insert the SD memory card into the digital keyboard “card slot”.
3. Press the (FUNCTION) button.
4. Scroll down using the arrow ( √ ) until (PLAYCARDUt) shown then press (ENTER).
5. Scroll down using the arrow ( √ ) until (CARDFormat) shown then press (ENTER) and (YES).
6. Wait until “ Complete! “ appears. Press “Exit”.
7. Then remove the SD card.

### **2<sup>nd</sup> Step: Transferring the New Rhythm Style from Computer to SD Card memory**

1. Upload the “New Oriental Rhythm” to PC.
2. Insert the SD card to the PC then open the folder (MUSICDAT).
3. Drag or Copy the “New Rhythm Style” from PC to SD card folder (MUSICDAT).
4. Remove the SD from the computer card slot.

### **3<sup>rd</sup> Step: Loading the New Rhythm Style from SD Card to Digital Keyboard**

1. Insert the SD card into digital keyboard card slot.
2. Press the (USER RHYTHM) button.
3. Use the dial or (- , +) buttons to specify the user rhythm number (NO DATA).
4. While holding down the (FUNCTION) button, press the (LOAD/SAVE) button.
5. Use the dial or (- , +) buttons to display the file you want to import.
6. Press the (ENTER) button.
7. In response to the “SURE?” message that appears, press the (YES) button to load.
8. Repeat the same procedure from Number 3-8 upon loading the other rhythm style. Load the rhythm style one by one.

## B. Loading New Style from Computer to Casio AT-3/5

Note: Use “Type A-B USB Cable” for connection from digital keyboard to Computer.

1. Upload “Data Manager Software” into the Computer by accessing Casio site: <http://support.casio.com/en/support/download.php?cid=008&pid=20> then Clicking *Middle East EMI* and click specific models (Example: AT-3) for “DataManager Software” from “Downloads”.
2. Upload the “New Oriental Rhythm” from Casio site: [http://www.casio-intl.com/mea/en/emi/sp/orient\\_al\\_keyboard/](http://www.casio-intl.com/mea/en/emi/sp/orient_al_keyboard/) in “Download” to PC.
3. Once “DataManager Software” uploaded to Computer, open the file (datamanager.exe).
4. Connect “Type A-B USB cable” from Computer to digital Keyboard USB port.
5. Turn on digital keyboard power button.
6. Automatically 2 windows appear on the Computer screen, one from the left side (PC user data file) and right side “Keyboard window (AT-3 for example)”. Normal setup shows “tone” shown upper left corner window box.

7. Drag one by one the “data” (new rhythm styles) from computer to left side (PC user data files).
8. Click the (Tone) window box then choose (Rhythm).
9. Transfer the new data by dragging from left side (PC user data files) to right side “Keyboard window”(AT-3).
10. To delete the data, drag the unwanted rhythm to the trash icon (upper right corner).

**New Oriental Rhythm Styles Name: ( Access this data from Casio site and upload this data to your PC )**

1. Ayoub
2. Baladi
3. Dance-OR
4. Fox
5. Iraki
6. Karachi
7. Katakoft
8. Khebiti
9. Laff
10. Maallay
11. Maksoum
12. Maksoums
13. Mix-S-W
14. Rhumba
15. Roboa
16. Saedy 1
17. Saedy 2
18. Valse
19. Wehda
20. Zaffa