

## Specifications

|                            |                                |   |                     |
|----------------------------|--------------------------------|---|---------------------|
| Model                      |                                | WK-7500   | CTK-7000            |
| Keyboard                   |                                | 76 piano-style keys   | 61 piano-style keys |
|                            | Touch Response                 | 2 sensitivity levels, Off   |                     |
| Sound Source               |                                | AHL (Tri-element)   |                     |
| Polyphony (Maximum)        |                                | 64  |                     |
| Built-in Tones             |                                | 800 (including 50 Drawbar Organ tones)  |                     |
|                            | Stereo Sampled Piano Tones     | ●   |                     |
| User Tones                 |                                | 100 (Tone Editor) + 50 (Drawbar Organ)  |                     |
| Drawbar Organ Function     |                                | 9 drawbars (16', 5 1/3', 8', 4', 2 2/3', 2', 1 3/5', 1 1/3', 1')  |                     |
|                            | Built-in Drawbar Organ Tones   | 50 (included in 800 built-in tones)   |                     |
|                            | User Drawbar Organ Tones       | 50  |                     |
|                            | Percussion                     | Second / Third  |                     |
|                            | Click                          | On / Off  |                     |
|                            | Rotary Effect                  | Fast / Slow (Uses DSP.)   |                     |
| Digital Effects            | Reverb                         | 10 types  |                     |
|                            | Chorus                         | 5 types (simultaneous use with DSP not supported)   |                     |
|                            | DSP                            | 100 built-in, 100 user (simultaneous use with Chorus not supported)   |                     |
| Built-in Rhythms           |                                | 250   |                     |
|                            | Ethnic Rhythms (Latin / Other) | 106 (39 / 67)   |                     |
|                            | For Piano Play                 | 20  |                     |
| User Rhythms               |                                | 100 (Pattern Sequencer)   |                     |
| Auto Accompaniment         |                                | CASIO chord, Fingered 1, Fingered 2 (6th off), Fingered 3 (on bass), Full Range Chord   |                     |
|                            | Controllers                    | Start/Stop, Intro, Normal/Fill-in, Variation/Fill-in, Synchro/Ending (accompaniment volume adjustable)  |                     |
| Pattern Sequencer          |                                | Real-time recording, step recording, quantize, Easy Edit, Event Editor, part parameters (100 user rhythms)  |                     |
| Song Sequencer             |                                | Real-time recording (Easy Rec, Multi-track Rec), step recording, song edit, track edit, event edit (delete, copy, insert, quantize), punch-in/out |                     |
|                            | User Song                      | 5 songs, 17 tracks per song (1 system track + 16 multi tracks)  |                     |
|                            | Approximate Capacity           | 30,000 notes (5 songs total)  |                     |
| Demonstration Songs        |                                | 5   |                     |
| Song Controller            |                                | Play/Stop, Fast Forward, Fast Backward, Pause, Repeat (song volume adjustable)  |                     |
| Metronome                  |                                | 0, 2, 3, 4, 5, 6 beats  |                     |
|                            | Tempo Range                    | 30 to 255 per minute (tempo adjustable by tapping beat)   |                     |
| Audio Recording / Playback | Recording Source               | Keyboard play, keyboard play with Auto Accompaniment and with Music Preset, Song Sequencer playback, sound input from EXT IN (INST IN, MIC IN)    |                     |
|                            | Recording Capacity             | Up to 5 audio files (maximum recording time: approximately 13 minutes for a single audio file)  |                     |
|                            | Requirement                    | SD or SDHC memory card, 2GB to 32GB   |                     |
| Mixer                      |                                | 32 channels + EXT IN (INST IN, MIC IN), 9-slider operation  |                     |
| Registration               |                                | 6 sets × 16 banks (96 setups)   |                     |
| Music Presets              |                                | 305 presets with chord progression, chord edit  |                     |
|                            | User Presets                   | 100   |                     |
| One Touch Presets          |                                | 250   |                     |
| Auto Harmonizing           |                                | 12 types  |                     |
| Arpeggiator                |                                | 150 types   |                     |
| Scale Tuning               |                                | Equal temperament + 16 preset scales, Scale Fine Tune   |                     |
| Octave Shift               |                                | ±2 octaves  |                     |
| Layer                      |                                | ●   |                     |
| Split                      |                                | ● (variable split point)  |                     |
| Key Transpose              |                                | ±1 octave (-12 to +12 semitones)  |                     |
| Tuning Control             |                                | A4 = 415.5 - 440.0 - 456.9Hz  |                     |
| Pitch Bend Wheel           |                                | Pitch bend range: 0 to 12 semitones   |                     |
| Modulation Button          |                                | ●   |                     |
| Sliders                    |                                | 9   |                     |
| Dial                       |                                | ●   |                     |
| Display                    |                                | LCD with backlight  |                     |
| MIDI <sup>1</sup>          |                                | 16 channel multi-timbre received, GM Level 1 standard <sup>1</sup>  |                     |
| SD Memory Card Slot        | Supported Memory Card          | SD or SDHC memory card, 2GB to 32GB   |                     |
|                            | Functions                      | SMF playback (up to 320KB per file), file storage, file recall, file delete, card format  |                     |
|                            | Save / Load                    | Registration setups, user rhythms, user tones, user drawbar organ tones, user DSPs, user music presets, song sequencer, audio recording files     |                     |
| Terminals                  | USB <sup>2</sup>               | ● <sup>2</sup>  |                     |
|                            | PHONES                         | ● (Stereo standard jack)  |                     |
|                            | LINE OUT                       | ● (L/MONO, R for each; Standard jack)   |                     |
|                            | INST IN                        | ● (Mono standard jack)  |                     |
|                            | MIC IN                         | ● (Mono standard jack)  |                     |
|                            | AUDIO IN                       | ● (Stereo mini jack)  |                     |
|                            | SUSTAIN/ASSIGNABLE             | ● (Standard jack)   |                     |
|                            | DC IN                          | ● (12V)   |                     |
| Speakers                   | Size                           | 12cm × 2 + 3cm × 2  |                     |
|                            | Bass-reflex System             | ●   |                     |
|                            | Speaker ON / OFF               | ●   |                     |
| Amplifier                  |                                | 7W + 7W   |                     |
| Power                      |                                | Batteries: D size × 6 / AC Adaptor: AD-A12150LW   |                     |
| Size (W × D × H)           |                                | 1,187 × 399 × 149mm   | 945 × 378 × 132mm   |
| Weight                     |                                | 8.9kg   | 6.8kg               |
| Accessories                |                                | AC adaptor (AD-A12150LW), music stand   |                     |

\*1 These products are not equipped with MIDI terminals. MIDI communication between the product and a computer is performed using the USB port.

\*2 Supported operating systems: Windows® XP Home Edition (SP2 or later), Windows® XP Professional (SP2 or later, 32-bit), Windows Vista® (32-bit), Windows® 7 (32-bit, 64-bit), Mac OS® X (10.3.9, 10.4.11 or later, 10.5.8 or later, 10.6.3 or later)

A USB cable is not included with this product. To connect this product to a computer, use a commercially available A-B type USB cable.